



# XOn NTX Toolkit

XOn Software GmbH

<http://www.xon.de>

# Table of Contents

<b>Part I Introduction</b>	<b>4</b>
<b>Part II XOnNTX_PortIO32_VIs</b>	<b>5</b>
1 In Port .....	5
2 IOClose .....	6
3 IOOpen .....	7
4 IORead .....	8
5 IOWrite .....	9
6 Out Port .....	10
<b>Part III XOnNTX_BaseIO_VIs</b>	<b>11</b>
1 XOnNTX_Close .....	11
2 XOnNTX_GetDiagnosis .....	13
3 XOnNTX_Open .....	16
4 XOnNTX_ReadPort .....	18
5 XOnNTX_Version .....	20
6 XOnNTX_WritePort .....	21
<b>Part IV XOnNTX_HardIO_VIs</b>	<b>23</b>
1 XOnNTX_DisablePortIO .....	23
2 XOnNTX_EnablePortIO .....	25
3 XOnNTX_GetPhysAddress .....	27
4 XOnNTX_GetPortIOMap .....	29
5 XOnNTX_InpB .....	31
6 XOnNTX_InpD .....	32
7 XOnNTX_InpW .....	33
8 XOnNTX_MapPhysMemory .....	34
9 XOnNTX_OutB .....	36
10 XOnNTX_OutD .....	37
11 XOnNTX_OutW .....	38
12 XOnNTX_PCICountDevice .....	39
13 XOnNTX_PCIFindDevice .....	41
14 XOnNTX_PCIGetConfig .....	43
15 XOnNTX_PCISetConfig .....	52
16 XOnNTX_SetPortIOMap .....	61
17 XOnNTX_UnmapPhysMemory .....	63
<b>Part V XOnNTX_ShareM_VIs</b>	<b>65</b>

1 XOnNTX_CloseSharedMemory .....	65
2 XOnNTX_CreateSharedMemory .....	67
3 XOnNTX_InfoSharedMemory .....	69
4 XOnNTX_OpenSharedMemory .....	71
5 XOnNTX_SMRBufClear .....	73
6 XOnNTX_SMRBufClose .....	75
7 XOnNTX_SMRBufCreate .....	77
8 XOnNTX_SMRBufInfo .....	79
9 XOnNTX_SMRBufOpen .....	82
10 XOnNTX_SMRBufRead .....	84
11 XOnNTX_SMRBufReadEx .....	86
12 XOnNTX_SMRBufWrite .....	88
13 XOnNTX_SMRBufWriteEx .....	90
<b>Part VI XOnNTX_UTILITY_VIs</b> .....	<b>92</b>
1 XOnNTX_MoveMemory .....	92
2 XOnNTX_ReadByte .....	94
3 XOnNTX_ReadDWord .....	96
4 XOnNTX_ReadMemory .....	98
5 XOnNTX_ReadString .....	100
6 XOnNTX_ReadWord .....	102
7 XOnNTX_WriteByte .....	104
8 XOnNTX_WriteDWord .....	106
9 XOnNTX_WriteMemory .....	108
10 XOnNTX_WriteString .....	110
11 XOnNTX_WriteWord .....	112
<b>Part VII Constants and Types</b> .....	<b>114</b>
1 XOnNTX_HardIO .....	114
PCI_COMMON_CONFIG .....	114
PCI_CONFIG .....	115
2 XOnNTX_BaseIO .....	116
IOHANDLE .....	116
XONNTX_DIAGINFO .....	117
3 XOnNTX_ShareM .....	118
SMEMHDL .....	118
SMEMINFO .....	119
SMRBUFHDL .....	120
SMRBUFINFO .....	121
<b>Part VIII Contact</b> .....	<b>122</b>



# 1 Introduction



This add-on library for LabVIEW under NT/W2K/XP enables port I/O-access, as well as memory access. Hardware access can also be realized with compatibility-VIs similar to the LabVIEW functions under Win9x.

Under Windows NT access to port-I/O is only permitted for drivers. The system allocates a certain address range for a driver. The XOn port I/O-driver allows the configuration of max 10 address ranges of variable size which can be accessed simultaneously. For the configuration of these address areas the "XOn Port I/O Manager" is shipped with the driver. Thus you can access address ranges that are normally managed by the system.



## 2 XOnNTX\_PortIO32\_VIs

### 2.1 In Port

This VI allows you to read either a single byte or word from the specified register address. The value is returned, in hexadecimal format, to Value.

#### Connector Pane



#### Controls and Indicators

 register address

 read a byte or a word (F:byte)

 value

## 2.2 IOClose

---

### Connector Pane



### Controls and Indicators

 **IOHandle**

 **OK?**

## 2.3 IOOpen

---

### Connector Pane



### Controls and Indicators

 IODevice

 IOHandle

## 2.4 IORead

### Connector Pane




### Controls and Indicators

-  IOHandle
-  IOPort
-  Type(Byte)
-  OK?
-  Value
-  IOHandle/dup

## 2.5 IOWrite

---

### Connector Pane



### Controls and Indicators

 IOHandle

 IOPort

 Value(0)

 Type(Byte)

 OK?


 IOHandle/dup

## 2.6 Out Port

This VI allows you to write a single byte or word to the specified register address.

---

### Connector Pane



### Controls and Indicators

 register address

 value

 write a byte or a word (F:byte)


## 3 XOnNTX\_BaselO\_VIs

### 3.1 XOnNTX\_Close

Closes an explicit or implicit driver handle. See XOnNTX\_Open for more information.

---

#### Connector Pane



#### Controls and Indicators



##### IOHandle

Driver handle.



##### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



##### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



##### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



##### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



##### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



##### status

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


**abc** **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 3.2 XOnNTX\_GetDiagnosis

Returns diagnostic information on the last call of a driver-function.

### Connector Pane



### Controls and Indicators

 **IOHandle**  
Driver-handle.

 **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **DiagInfo**  
Diagnostic information type.

**IoctlCode** Internal code of last called driver function

**Status** Status-Code of call (0=SUCCESS)

**Description** Textual description ("OK" on success)

 **ioctlCode**

Internal code of last called driver function.

 **Status**

Values are 32 bit values layed out as follows:



- Sev** is the severity code
  - 00 - Success
  - 01 - Informational
  - 10 - Warning
  - 11 - Error
- Bit 30-31
- c** is the Customer code flag
- Bit 29
- r** is a reserved bit
- Bit 28
- Facility** is the facility code
- Bit 16-27
- Code** is the facility's status code
- Bit 0-15

**Define the facility codes**  
 x2=FACILITY\_RPC\_RUNTIME  
 x3=FACILITY\_RPC\_STUBS  
 x4=FACILITY\_IO\_ERROR\_CODE

**Define the severity codes**  
 x0=STATUS\_SEVERITY\_SUCCESS  
 x1=STATUS\_SEVERITY\_INFORMATIONAL  
 x2=STATUS\_SEVERITY\_WARNING  
 x3=STATUS\_SEVERITY\_ERROR

 **Description**  
 Textual description ("OK" on success).

 **error out**  
 error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**  
 status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

**IOHandle/dup**

Duplicated Driver-handle.

## 3.3 XOnNTX\_Open


Opens the NT-Extension Driver and returns a handle to it usable from other XOnNTX functions.

Thus recommended, opening the driver is optional and will be done implicit by the driver DLL on the first call of any XOnNTX function that accepts a driver handle as input. The driver DLL always remembers the last implicit or explicit opened driver handle and uses this on any other XOnNTX functions called with a NULL-handle (NOT connected handle).

If not explicitly closed using XOnNTX\_Close, the driver DLL will close the remembered driver-handle (and only this) on DLL-unload (end of application).

WARNING: To avoid unused opened driver handles (wasting system resources) after end of application, either never use XOnNTX\_Open, or balance open calls with calls to XOnNTX\_Close.

### Connector Pane



### Controls and Indicators

#### IODevice

Optional parameter for future use. Do NOT use it.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### IOHandle

Handle to the opened driver. Use this an other XOnNTX functions that accept a handle.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred

before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


## 3.4 XOnNTX\_ReadPort

Reads a single value from the given IO-Port.

You may optionally define the Port-Type Byte, Word or Doubleword (defaults to Byte). In any case the returned value is of type Doubleword.

WARNING: Thus not necessary, using Porttypes other than Byte you should align the IOPort appropriately; 2-Byte for Word-, 4-Byte for Doubleword-Type.

### Connector Pane



### Controls and Indicators



#### IOHandle

Driver-handle.



#### IOPort

IO-Port to read a Byte, Word or Doubleword from.

For types other than Byte you should align the IOPort; 2-Byte for Word-, 4-Byte for Doubleword-Type.



#### Type(Byte)

Optional porttype, Byte, Word or Doubleword.



#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

**U32** Value

Value read from the given IOPort.

Independently of the give Port-Type always as Doubleword.

**IOHandle/dup**

Duplicated Driver-handle.

**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF** status

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**abc** source


source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 3.5 XOnNTX\_Version

Returns the Driver-Version as string and value.

---

### Connector Pane



### Controls and Indicators

 VersionString

 Version

<b>Low-Word</b>	Minor-Version-Number
<b>High-Word</b>	Major-Version-Number
<b>BIT-31</b>	Windows-9x Emulation-Flag 0 = Windows-2000/-NT Version 1 = Windows-9x Emulation
<b>BIT-30</b>	Demo-Flag Full-Demo 0 = NOT a Demo-Version 1 = DEMO-Version
<b>BIT-29</b>	Demo-Flag HardIO 0 = NOT a Demo-Version 1 = DEMO-Version
<b>BIT-28</b>	Demo-Flag Shared-Memory 0 = NOT a Demo-Version 1 = DEMO-Version


## 3.6 XOnNTX\_WritePort

Writes a single value to the given IO-Port.

You may optionally define the Port-Type Byte, Word or Doubleword (defaults to Byte).

**WARNING:** Thus not necessary, using Porttypes other than Byte you should align the IOPort appropriately; 2-Byte for Word-, 4-Byte for Doubleword-Type.

### Connector Pane



### Controls and Indicators



**IOHandle**

Driver-Handle.



**IOPort**

IO-Port to write a Byte, Word or Doubleword to.

Types other than Byte requires alignment; 2-Byte for Word-, 4-Byte for Doubleword-Type.



**Value**

Value to write.



**Type(Byte)**

Optional porttype, Byte, Word or Doubleword.



**error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



**status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **IOHandle/dup**

Duplicated Driver-Handle.

 **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


## 4 XOnNTX\_HardIO\_VIs

### 4.1 XOnNTX\_DisablePortIO

Disables direct port access in the range from 'PortStart' to 'PortEnd'.

---

#### Connector Pane



#### Controls and Indicators



**IOHandle**

Driver-handle.



**PortStart**

Start port address to disallow direct port access.



**PortEnd**

End port address.



**error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



**status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error,

if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


** IOHandle/dup**

Duplicated Driver-handle.

## 4.2 XOnNTX\_EnablePortIO

Enables direct port access in the range from 'PortStart' to 'PortEnd'.

### Connector Pane



### Controls and Indicators



**IOHandle**

Driver-handle.



**PortStart**

Start port address to allow direct port access.



**PortEnd**

End port address.



**error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



**status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error

input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


 **IOHandle/dup**

Duplicated Driver-handle.

## 4.3 XOnNTX\_GetPhysAddress

Returns the phys. address associated with the given virtual address.  
The virtual address should be mapped via XOnNTX\_MapPhysMemory.

### Connector Pane



### Controls and Indicators

#### **IOHandle**

Driver-handle.

#### **VirtAddr**

Virtual start address that should be mapped via XOnNTX\_MapPhysMemory.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **PhysAddr**

Phys. address associated with the given virtual address. Zero if phys. address is not available for the current process.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to

check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **IOHandle/dup**

Duplicated Driver-handle.

## 4.4 XOnNTX\_GetPortIOMap

Returns the current Port-IO mapping state for the current process.

Use this function before using XOnNTX\_EnablePortIO or XOnNTX\_DisablePortIO to save the current mapping state. Use XOnNTX\_SetPortIOMap after your direct port access to reset the mapping state.

### Connector Pane



### Controls and Indicators



**IOHandle**

Driver-handle.



**error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



**status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



**IOMap**

Port mapping state.

#### WARNING:

As this is an opaque data structure do not modify its contents. Use the IOMap in calls to XOnNTX\_SetPortIOMap only.

**IOHandle/dup**

Duplicated Driver-handle.

**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**source**


source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 4.5 XOnNTX\_InpB

Reads a single byte value (u8) from the given port via fast direct port access.  
WARNING: The given port MUST be in an allowed port-range.  
Use XOnNTX\_EnablePortIO to enable ports.

---

### Connector Pane



### Controls and Indicators

Port

Port to read the value from.

Byte

Read value.

Port/dup

Duplicated port.

## 4.6 XOnNTX\_InpD

Reads a single doubleword value (u32) from the given port via fast direct port access.  
WARNING: The given port MUST be in an allowed port-range.  
Use XOnNTX\_EnablePortIO to enable ports.

---

### Connector Pane



### Controls and Indicators

 **Port**

Port to read the value from.

 **DWord**

Read value.

 **Port/dup**

Duplicated port.

## 4.7

XOnNTX\_InpW

---

Reads a single word value (u16) from the given port via fast direct port access.  
WARNING: The given port MUST be in an allowed port-range.  
Use XOnNTX\_EnablePortIO to enable ports.

---

**Connector Pane****Controls and Indicators**

**U16** Port

Port to read the value from.

**U16** Word

Read value.

**U16** Port/dup


Duplicated port.

## 4.8 XOnNTX\_MapPhysMemory

Maps a physical address range into a process specific virtual address range to allow reading/writing directly from/to the memory. You should unmap the memory with XOnNTX\_UnmapPhysMemory after using the memory, not to block the virtual address range to long.

Use the utility functions to read/write from/to the virtual address range.

### Connector Pane



### Controls and Indicators

 **IOHandle**  
Driver-handle.

 **Length**  
Nr. of bytes to be mapped.

 **PhysAddr**  
Physical start address to be mapped.

 **Interface(Isa)**  
The bus-system over this physical address is accessible.

Mapping the computer-RAM the bus is not necessary. Mapping memory from a board it depends on the bus where board has been plugged in.

 **BusNumber(0)**  
Some computers do have more than one bus of the same type (PCI). In this case you have to select the correct busnr. Your PC-documentation should have information which slot belongs to what busnr.

 **ReadWrite(RO)**  
Allowed accesstype.

 **error in (no error)**  
error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF** status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**abc** source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

**U32** VirtAddr

Mapped virtual start address.

**err** error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF** status

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**abc** source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

**IOHandle/dup**

Duplicated Driver-handle.

## 4.9 XOnNTX\_OutB

Writes a single byte value (u8) to the given port via fast direct port access.  
WARNING: The given port MUST be in an allowed port-range.  
Use XOnNTX\_EnablePortIO to enable ports.

---

### Connector Pane



### Controls and Indicators

**U16** Port

Port to write the value to.

**U8** Byte(0)

Value to write.

**U16** Port/dup

Duplicated port.

## 4.10 XOnNTX\_OutD

Writes a single doubleword value (u32) to the given port via fast direct port access.  
WARNING: The given port MUST be in an allowed port-range.  
Use XOnNTX\_EnablePortIO to enable ports.

---

### Connector Pane



### Controls and Indicators

Port

Port to write the value to.

DWord

Value to write.

Port/dup

Duplicated port.

## 4.11 XOnNTX\_OutW


Writes a single word value (u16) to the given port via fast direct port access.

WARNING: The given port MUST be in an allowed port-range.

Use XOnNTX\_EnablePortIO to enable ports.

---

### Connector Pane



### Controls and Indicators

 **Port**

Port to write the value to.

 **Word**

Value to write.

 **Port/dup**


Duplicated port.

## 4.12 XOnNTX\_PCICountDevice

Counts nr. of PCI-devices.

---

### Connector Pane



### Controls and Indicators

 **IOHandle**  
Driver-handle.

 **VendorID**  
Vendor-ID of the PCI-device to restrict counting for.

Use xFFFF not to restrict counting.

 **DeviceID**  
Device-ID to restrict the counting for.

Use xFFFF not to restrict counting on any Device-ID.

 **error in (no error)**  
error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**  
status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**  
code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**  
source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **error out**  
error out is a cluster that describes the error status after this VI executes. If an error occurred

before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

** IOHandle/dup**

Duplicated Driver-handle.


** Devices**

Nr. of devices found.

## 4.13 XOnNTX\_PCIFindDevice

Find the Bus- and Slot-Number of the specified device.

### Connector Pane



### Controls and Indicators

#### **IOHandle**

Driver-handle.

#### **VendorID**

Vendor-ID of PCI-device to find.

Use xFFFF to find devices of any vendor.

#### **DeviceID**

Device-ID of PCI-device to find.

Use xFFFF to find any device.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **Nth(1)**

Find the n'th [1..] PCI-device.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **IOHandle/dup**

Duplicated Driver-handle.

#### **BusNo**


Busnr. the device has been found.

#### **SlotNo**

## 4.14 XOnNTX\_PCIGetConfig

Get configuration of a specific PCI-device.

### Connector Pane



### Controls and Indicators

#### **IOHandle**

Driver-handle.

#### **BusNo(0)**

Busnr. of the CPI-device.

#### **SlotNo**

BIT-description

- 0..4**      Devicenummer
- 5..7**      Functionnummer
- ...          Reserved

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **PCICfg**

Reference notes for PCI configuration fields:

- ro** these field are read only. changes to these fields are ignored
- ro+** these field are intended to be read only and should be initialized by the system to their proper values. However, driver may change these settings.

All resources consumed by a PCI device start as uninitialized under NT. An uninitialized memory or I/O base address can be determined by checking it's corresponding enabled bit in the PCI\_COMMON\_CONFIG.Command value. An InterruptLine is uninitialized if it contains the value of -1.

#### VendorID

Vendor-ID // ro

#### DeviceID

Device-Id // ro

#### Command

Device Control

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Command  
//  
#define PCI_ENABLE_IO_SPACE 0x0001  
#define PCI_ENABLE_MEMORY_SPACE 0x0002  
#define PCI_ENABLE_BUS_MASTER 0x0004  
#define PCI_ENABLE_SPECIAL_CYCLES 0x0008  
#define PCI_ENABLE_WRITE_AND_INVALIDATE 0x0010  
#define PCI_ENABLE_VGA_COMPATIBLE_PALETTE 0x0020  
#define PCI_ENABLE_PARITY 0x0040 // (ro+)  
#define PCI_ENABLE_WAIT_CYCLE 0x0080 // (ro+)  
#define PCI_ENABLE_SERR 0x0100 // (ro+)  
#define PCI_ENABLE_FAST_BACK_TO_BACK 0x0200 // (ro)
```

#### Status

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Status  
//  
#define PCI_STATUS_FAST_BACK_TO_BACK 0x0080 // (ro)  
#define PCI_STATUS_DATA_PARITY_DETECTED 0x0100  
#define PCI_STATUS_DEVSEL 0x0600 // 2 bits wide  
#define PCI_STATUS_SIGNALED_TARGET_ABORT 0x0800  
#define PCI_STATUS_RECEIVED_TARGET_ABORT 0x1000  
#define PCI_STATUS_RECEIVED_MASTER_ABORT 0x2000  
#define PCI_STATUS_SIGNALED_SYSTEM_ERROR 0x4000  
#define PCI_STATUS_DETECTED_PARITY_ERROR 0x8000
```

#### RevID

#### ProgIF

#### SubCI

#### BaseCI

#### CacheLS

#### LatTim

#### HType

```
//  
// Bit encodings for PCI_COMMON_CONFIG.HeaderType  
//  
#define PCI_MULTIFUNCTION          0x80  
#define PCI_DEVICE_TYPE           0x00  
#define PCI_BRIDGE_TYPE           0x01
```

**U8** BIST**E06** HEADER\_TYPE\_0**U32** BaseAddr1

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE          ro  
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK  ro  
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro  
  
0          PCI_TYPE_32BIT  
2          PCI_TYPE_20BIT  
4          PCI_TYPE_64BIT
```

**U32** BaseAddr2

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE          ro  
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK  ro  
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro  
  
0          PCI_TYPE_32BIT  
2          PCI_TYPE_20BIT  
4          PCI_TYPE_64BIT
```

**U32** BaseAddr3

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE          ro  
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK  ro  
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro  
  
0          PCI_TYPE_32BIT  
2          PCI_TYPE_20BIT  
4          PCI_TYPE_64BIT
```

**U32** BaseAddr4

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro
0	PCI_TYPE_32BIT	
2	PCI_TYPE_20BIT	
4	PCI_TYPE_64BIT	

**U32** BaseAddr5

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro
0	PCI_TYPE_32BIT	
2	PCI_TYPE_20BIT	
4	PCI_TYPE_64BIT	

**U32** BaseAddr6

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro
0	PCI_TYPE_32BIT	
2	PCI_TYPE_20BIT	
4	PCI_TYPE_64BIT	

**U32** CIS**U16** SubVenID**U16** SubSysID**U32** ROMBaseAddr

// Bit encodes for ROMBaseAddr

x00000001 = PCI\_ROMADDRESS\_ENABLED

**U32** Res1

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

**U32 Res2**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

**U8 IRQLn****U8 IRQPin****U8 MinGr****U8 MaxLat****error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32 code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**abc source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

**IOHandle/dup**

Duplicated Driver-handle.

### PCIConfig

Reference notes for PCI configuration fields:

- ro** these field are read only. changes to these fields are ignored
- ro+** these field are intended to be read only and should be initialized by the system to their proper values. However, driver may change these settings.

All resources consumed by a PCI device start as uninitialized under NT. An uninitialized memory or I/O base address can be determined by checking it's corresponding enabled bit in the PCI\_COMMON\_CONFIG.Command value.

An InterruptLine is initialized if it contains the value of -1.

#### VendorID

Read only.  
Identifies the manufacturer of the device.

#### DeviceID

Read only.  
Identifies the particular device. This value is assigned by the manufacturer.

#### Command

Accesses the PCI device's control register. Writing a zero to this register renders the device logically disconnected from the PCI bus except for configuration access. Otherwise, the functionality of the register is device-dependent.

Bit encodings for PCI\_COMMON\_CONFIG.Command

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Command  
//  
#define PCI_ENABLE_IO_SPACE           0x0001  
#define PCI_ENABLE_MEMORY_SPACE      0x0002  
#define PCI_ENABLE_BUS_MASTER        0x0004  
#define PCI_ENABLE_SPECIAL_CYCLES    0x0008  
#define PCI_ENABLE_WRITE_AND_INVALIDATE 0x0010  
#define PCI_ENABLE_VGA_COMPATIBLE_PALETTE 0x0020  
#define PCI_ENABLE_PARITY             0x0040 // (ro+)  
#define PCI_ENABLE_WAIT_CYCLE         0x0080 // (ro+)  
#define PCI_ENABLE_SERR               0x0100 // (ro+)  
#define PCI_ENABLE_FAST_BACK_TO_BACK 0x0200 // (ro)
```

#### Status

Accesses the PCI device's status register. The functionality of this register is device-dependent.

Bit encodings for PCI\_COMMON\_CONFIG.Status

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Status  
//  
#define PCI_STATUS_FAST_BACK_TO_BACK 0x0080 // (ro)  
#define PCI_STATUS_DATA_PARITY_DETECTED 0x0100  
#define PCI_STATUS_DEVSEL            0x0600 // 2 bits wide  
#define PCI_STATUS_SINGALED_TARGET_ABORT 0x0800  
#define PCI_STATUS_RECEIVED_TARGET_ABORT 0x1000  
#define PCI_STATUS_RECEIVED_MASTER_ABORT 0x2000  
#define PCI_STATUS_SINGALED_SYSTEM_ERROR 0x4000  
#define PCI_STATUS_DETECTED_PARITY_ERROR 0x8000
```

**► U8 RevID**

RevisionID

Specifies the revision level of the device described by the DeviceID member. This value is assigned by the manufacturer.

**► U8 ProgIF**

Identifies the register-level programming interface, if any, for the device, according to the PCI classification scheme.

**► U8 SubCI**

SubClass

Identifies the subtype, if any, of the device, according to the PCI classification scheme.

**► U8 BaseCI**

BaseClass

Identifies type of the device, according to the PCI classification scheme.

**► U8 CacheLS**

CacheLineSize

Contains the system cache line size in 32-bit units. This member is relevant only for PCI busmaster devices. The system determines this value during the boot process.

**► U8 LatTim**

LatencyTimer

Contains the value of the latency timer in units of PCI bus clocks. This member is relevant only for PCI busmaster devices. The system determines this value during the boot process.

**► U8 HType**

HeaderType

The system ORs the value of this member with PCI\_MULTIFUNCTION, if appropriate to the device. The value of this member indicates the PCI\_HEADER\_TYPE\_0 layout that follows. Bit encodings for PCI\_COMMON\_CONFIG.HeaderType

x80	PCI_MULTIFUNCTION
x00	PCI_DEVICE_TYPE
x01	PCI_BRIDGE_TYPE

**► U8 BIST**

Built In Self Test

Zero indicates that the device does not support built-in self test. Otherwise, the device supports built-in self test according to the PCI standard.

**► 008 HEADER\_TYPE\_0****► U32 BaseAddr1**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr2**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr3**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr4**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr5**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0 PCI\_TYPE\_32BIT  
2 PCI\_TYPE\_20BIT  
4 PCI\_TYPE\_64BIT

**U32 BaseAddr6**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001 PCI\_ADDRESS\_IO\_SPACE ro  
x00000006 PCI\_ADDRESS\_MEMORY\_TYPE\_MASK ro  
x00000008 PCI\_ADDRESS\_MEMORY\_PREFETCHABLE ro

0 PCI\_TYPE\_32BIT  
2 PCI\_TYPE\_20BIT  
4 PCI\_TYPE\_64BIT

**U32 CIS****U16 SubVenID****U16 SubSysID****U32 ROMBaseAddr**

// Bit encodes for ROMBaseAddr

x00000001 = PCI\_ROMADDRESS\_ENABLED

**U32 Res1****U32 Res2****U8 IRQLn**

Interruptline

**U8 IRQPin**

Interruptpin

**U8 MinGr**

MinimumGrant

**U8 MaxLat**

MaximumLatency

**U8 DevSpecific**


Contains any device-specific initialization information that is available.

**U8**

## 4.15 XOnNTX\_PCISetConfig

Set configuration of a specific PCI-device.

### Connector Pane



### Controls and Indicators



#### IOHandle

Driver-handle.



#### BusNo(0)

Busnr. of the CPI-device.



#### SlotNo

BIT-description

0..4      Devicenumber

5..7      Functionnumber

...      Reserved



#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



#### PCIConfig

Reference notes for PCI configuration fields:

- ro** these field are read only. changes to these fields are ignored
- ro+** these field are intended to be read only and should be initialized by the system to their proper values. However, driver may change these settings.

All resources consumed by a PCI device start as uninitialized under NT. An uninitialized memory or I/O base address can be determined by checking it's corresponding enabled bit in the PCI\_COMMON\_CONFIG.Command value.  
An InterruptLine is uninitialized if it contains the value of -1.

#### **U16** VendorID

Read only.  
Identifies the manufacturer of the device.

#### **U16** DeviceID

Read only.  
Identifies the particular device. This value is assigned by the manufacturer.

#### **U16** Command

Accesses the PCI device's control register. Writing a zero to this register renders the device logically disconnected from the PCI bus except for configuration access. Otherwise, the functionality of the register is device-dependent.  
Bit encodings for PCI\_COMMON\_CONFIG.Command

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Command  
//  
#define PCI_ENABLE_IO_SPACE           0x0001  
#define PCI_ENABLE_MEMORY_SPACE      0x0002  
#define PCI_ENABLE_BUS_MASTER        0x0004  
#define PCI_ENABLE_SPECIAL_CYCLES    0x0008  
#define PCI_ENABLE_WRITE_AND_INVALIDATE 0x0010  
#define PCI_ENABLE_VGA_COMPATIBLE_PALETTE 0x0020  
#define PCI_ENABLE_PARITY             0x0040 // (ro+)  
#define PCI_ENABLE_WAIT_CYCLE         0x0080 // (ro+)  
#define PCI_ENABLE_SERR               0x0100 // (ro+)  
#define PCI_ENABLE_FAST_BACK_TO_BACK  0x0200 // (ro)
```

#### **U16** Status

Accesses the PCI device's status register. The functionality of this register is device-dependent.  
Bit encodings for PCI\_COMMON\_CONFIG.Status

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Status  
//  
#define PCI_STATUS_FAST_BACK_TO_BACK  0x0080 // (ro)  
#define PCI_STATUS_DATA_PARITY_DETECTED 0x0100  
#define PCI_STATUS_DEVSEL             0x0600 // 2 bits wide  
#define PCI_STATUS_SIGNALED_TARGET_ABORT 0x0800  
#define PCI_STATUS_RECEIVED_TARGET_ABORT 0x1000  
#define PCI_STATUS_RECEIVED_MASTER_ABORT 0x2000  
#define PCI_STATUS_SIGNALED_SYSTEM_ERROR 0x4000  
#define PCI_STATUS_DETECTED_PARITY_ERROR 0x8000
```

#### **U8** RevID

RevisionID

Specifies the revision level of the device described by the DeviceID member. This value is assigned by the manufacturer.

#### ProgIF

Identifies the register-level programming interface, if any, for the device, according to the PCI classification scheme.

#### SubCl

SubClass

Identifies the subtype, if any, of the device, according to the PCI classification scheme.

#### BaseCl

BaseClass

Identifies type of the device, according to the PCI classification scheme.

#### CacheLS

CacheLineSize

Contains the system cache line size in 32-bit units. This member is relevant only for PCI busmaster devices. The system determines this value during the boot process.

#### LatTim

LatencyTimer

Contains the value of the latency timer in units of PCI bus clocks. This member is relevant only for PCI busmaster devices. The system determines this value during the boot process.

#### HType

HeaderType

The system ORs the value of this member with PCI\_MULTIFUNCTION, if appropriate to the device. The value of this member indicates the PCI\_HEADER\_TYPE\_0 layout that follows. Bit encodings for PCI\_COMMON\_CONFIG.HeaderType

x80	PCI_MULTIFUNCTION
x00	PCI_DEVICE_TYPE
x01	PCI_BRIDGE_TYPE

#### BIST

Built In Self Test

Zero indicates that the device does not support built-in self test. Otherwise, the device supports built-in self test according to the PCI standard.

#### HEADER\_TYPE\_0

##### BaseAddr1

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr2**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr3**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr4**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr5**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr6**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

 **CIS**

 **SubVenID**

 **SubSysID**

 **ROMBaseAddr**

// Bit encodes for ROMBaseAddr

x00000001 = PCI\_ROMADDRESS\_ENABLED

 **Res1**

 **Res2**

 **IRQLn**

Interruptline

 **IRQPin**

Interruptpin

 **MinGr**

MinimumGrant

 **MaxLat**

MaximumLatency

 **DevSpecific**

Contains any device-specific initialization information that is available.

### **PCICfg**

Reference notes for PCI configuration fields:

**ro** these field are read only. changes to these fields are ignored

**ro+** these field are intended to be read only and should be initialized by the system to their proper values. However, driver may change these settings.

All resources consumed by a PCI device start as uninitialized under NT. An uninitialized memory or I/O base address can be determined by checking it's corresponding enabled bit in the

PCI\_COMMON\_CONFIG.Command value.  
An InterruptLine is initialized if it contains the value of  
-1.

**U16** VendorID

Vendor-ID // ro

**U16** DeviceID

Device-Id // ro

**U16** Command

Device Control

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Command  
//  
#define PCI_ENABLE_IO_SPACE          0x0001  
#define PCI_ENABLE_MEMORY_SPACE     0x0002  
#define PCI_ENABLE_BUS_MASTER       0x0004  
#define PCI_ENABLE_SPECIAL_CYCLES   0x0008  
#define PCI_ENABLE_WRITE_AND_INVALIDATE 0x0010  
#define PCI_ENABLE_VGA_COMPATIBLE_PALETTE 0x0020  
#define PCI_ENABLE_PARITY           0x0040 // (ro+)  
#define PCI_ENABLE_WAIT_CYCLE       0x0080 // (ro+)  
#define PCI_ENABLE_SERR             0x0100 // (ro+)  
#define PCI_ENABLE_FAST_BACK_TO_BACK 0x0200 // (ro)
```

**U16** Status

```
//  
// Bit encodings for PCI_COMMON_CONFIG.Status  
//  
#define PCI_STATUS_FAST_BACK_TO_BACK 0x0080 // (ro)  
#define PCI_STATUS_DATA_PARITY_DETECTED 0x0100  
#define PCI_STATUS_DEVSEL           0x0600 // 2 bits wide  
#define PCI_STATUS_SINGALED_TARGET_ABORT 0x0800  
#define PCI_STATUS_RECEIVED_TARGET_ABORT 0x1000  
#define PCI_STATUS_RECEIVED_MASTER_ABORT 0x2000  
#define PCI_STATUS_SINGALED_SYSTEM_ERROR 0x4000  
#define PCI_STATUS_DETECTED_PARITY_ERROR 0x8000
```

**U8** RevID**U8** ProgIF**U8** SubCI**U8** BaseCI**U8** CacheLS**U8** LatTim**U8** HType

```
//  
// Bit encodings for PCI_COMMON_CONFIG.HeaderType  
//  
#define PCI_MULTIFUNCTION           0x80  
#define PCI_DEVICE_TYPE             0x00  
#define PCI_BRIDGE_TYPE             0x01
```

**U8** BIST**E06** HEADER\_TYPE\_0

**U32 BaseAddr1**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr2**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr3**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr4**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

x00000001	PCI_ADDRESS_IO_SPACE	ro
x00000006	PCI_ADDRESS_MEMORY_TYPE_MASK	ro
x00000008	PCI_ADDRESS_MEMORY_PREFETCHABLE	ro

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

**U32 BaseAddr5**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

**U32 BaseAddr6**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

**U32 CIS****U16 SubVenID****U16 SubSysID****U32 ROMBaseAddr**

// Bit encodes for ROMBaseAddr

x00000001 = PCI\_ROMADDRESS\_ENABLED

**U32 Res1**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro

0 PCI_TYPE_32BIT
2 PCI_TYPE_20BIT
4 PCI_TYPE_64BIT
```

**U32 Res2**

Bit encodes for PCI\_COMMON\_CONFIG.BaseAddrx

```
x00000001 PCI_ADDRESS_IO_SPACE ro
x00000006 PCI_ADDRESS_MEMORY_TYPE_MASK ro
x00000008 PCI_ADDRESS_MEMORY_PREFETCHABLE ro
```

0	PCI_TYPE_32BIT
2	PCI_TYPE_20BIT
4	PCI_TYPE_64BIT

 **IRQLn**

 **IRQPin**

 **MinGr**

 **MaxLat**

### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

### **IOHandle/dup**


Duplicated Driver-handle.

## 4.16 XOnNTX\_SetPortIOMap

Resets the Port-IO mapping state of the current process.

Use this function as counterpart to XOnNTX\_GetPortIOMap to reset the mapping state. This will revoke all state changes from calls to XOnNTX\_EnablePortIO or XOnNTX\_DisablePortIO.

### Connector Pane



### Controls and Indicators



**IOHandle**

Driver-handle.



**IOMap**

Port mapping state to set.

#### WARNING:

Use IOMap's returned from calls to XOnNTX\_GetPortIOMap only.



**error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



**status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



**IOHandle/dup**

Duplicated Driver-handle.

 **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 4.17 XOnNTX\_UnmapPhysMemory

Unmaps the physical address range of the given virtual address range. The given start address (VirtAdr) MUST be the result of a mapping operation via XOnNTX\_MapPhysMemory. After unmapping, the virtual address range is no longer allowed to be read or written.

### Connector Pane



### Controls and Indicators

 **IOHandle**  
Driver-handle.

 **VirtAddr**  
Virtual start address that has been mapped via XOnNTX\_MapPhysMemory.

 **error in (no error)**  
error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**  
status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**  
code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**  
source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **error out**  
error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **IOHandle/dup**

Duplicated Driver-handle.


## 5 XOnNTX\_ShareM\_VIs

### 5.1 XOnNTX\_CloseSharedMemory

Closes a shared memory object handle. Does not remove the shared memory object if other users of the shared memory exist.

Returns the nr. of users left.

#### Connector Pane



#### Controls and Indicators

##### **SMemHdl**

Handle of an opened shared memory object.

##### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

##### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

##### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

##### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

##### **UsersLeft**

Nr. of users left after closing.

##### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to

check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 5.2 XOnNTX\_CreateSharedMemory

Creates a new or opens an existing shared memory object (named or unnamed). Returns a handle to the shared memory object and a virtual address pointer to the shared memory. Use the utility functions to read/write from/to the shared memory.

### Connector Pane



### Controls and Indicators

#### **Name**

Name of shared-memory object (optional).  
Named shared memory objects can be opened from other processes in the system.

#### **MaxSize**

Max. size of the shared memory in bytes.

#### **ReadOnly(F)**

True : Create/Open for reading from the shared memory only  
False: Create/Open for reading and writing.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **IOHandle**

Driver-handle.

 **SMemHdl**

Handle to the created/opened shared memory object.

 **VirtAddr**

Virtual address of the shared memory.

Use this address with the utility functions to access the memory.

 **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **IOHandle/dup**

Duplicated Driver-handle.

## 5.3 XOnNTX\_InfoSharedMemory

Returns information on an existing shared memory object.

You may give an open shared memory handle or the name of a shared memory object to ask for information.

### Connector Pane



### Controls and Indicators

 **SMemHdl**

 **Name**

Name of shared-memory object (optional).

 **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **SMemHdl/dup**

 **SMemInfo**

Structure with information on shared memory objects.

 **Name**

Name of shared memory object. Empty if unnamed.

**U32 Users**

Nr. of users of the shared memory object.

**U32 Size**

Max. nr. of bytes the shared memory can hold.

**U32 VirtAddr**

Virtual address of the shared memory.

May be zero if shared memory object exists but has not been opened from the current process.

**TF ReadOnly**

True : Shared memory object is opened for reading only

False: Shared memory object can be read or written.

**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32 code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


**abc source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 5.4 XOnNTX\_OpenSharedMemory

Opens an existing shared memory object (named or unnamed).  
Returns a handle to the shared memory object and a virtual address pointer to the shared memory.  
Use the utility functions to read/write from/to the shared memory.

### Connector Pane



### Controls and Indicators

#### **Name**

Name of shared-memory object (optional).  
Named shared memory objects can be opened from other processes in the system.

#### **ReadOnly(F)**

True : Create/Open for reading from the shared memory only  
False: Create/Open for reading and writing.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **IOHandle**

Driver-handle.

** Inheritable(T)**

True : The shared memory handle can be inherited by newly created processes.

False: The shared memory object handle cannot be inherited.

** SMemHdl**

Handle to the opened shared memory object.

** VirtAddr**

Virtual address of the shared memory.

Use this address with the utility functions to access the memory.

** error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

** IOHandle/dup**

Duplicated Driver-handle.

## 5.5 XOnNTX\_SMRBufClear

Clears the ring-buffer.

### Connector Pane



### Controls and Indicators

#### **SMRBuf**

Handle of a ring-buffer.

XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **ResWrtCnt(T)**

True : Reset write-counter to zero.

False: Do not reset the write-counter

The write-counter counts the nr. of bytes ever written to the buffer.

#### **SMRBuf/dup**

Duplicated ring-buffer handle.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error,

if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**


source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 5.6 XOnNTX\_SMRBufClose

Closes an open ring-buffer.

Closing a ring-buffer removes the buffer only if it is the last process that uses the buffer. If not, the buffer-contents will be kept and only administration structures are cleared.

### Connector Pane



### Controls and Indicators

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### SMRBuf

Handle of a ring-buffer.

XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


**abc** **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 5.7 XOnNTX\_SMRBufCreate

Creates a new or opens an existing ring-buffer based on shared memory. Returns a handle to the ring-buffer.

### Connector Pane



### Controls and Indicators

#### Name

Name of ring-buffer (optional).  
Named ring-buffers can be opened from other processes in the system.

#### BufSize

Size in bytes the ring-buffer can hold.  
The size will be internally aligned according to the 'Align' parameter.

#### EvtMode(No)

Eventmode.  
On Eventmodes other than 'NoEvt' the ring-buffer administration creates a named Read- and/or Write-Eventobject that may be used to synchronize read- and write-operations.  
A read-event will be signaled if any ring-buffer user reads data or clears the ring-buffer.  
A write-event will be signaled on write-operations.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **IOHandle**

Driver-handle.

#### **Align(1)**

Alignment of the ring-buffer.

The ring-buffer administration forces sizes on read-/write-operations to be aligned according to this parameter.

Example: If buffer should hold only 32-BIT integers set 'Align' to 4 (the byte size of int32)

#### **MtxWaitMS(10)**

Mutexwait Timeout (optional).

The buffer administration always creates a named mutex-object for a ring-buffer. It is used to synchronize the access to internal structures for parallel processes. While one process is reading or writing to the buffer other processes wait on this mutex-object.

The 'MtxWaitMS' parameter sets the timeout value in milliseconds for this wait-operation.

If a wait timed out on a read or write, the function will return an error.

#### **SMRBuf**

Handle of the new or opened shared memory based ring-buffer.

Use this handle with other XOnNTX\_SMRB.. functions.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


#### **IOHandle/dup**

Duplicated Driver-handle.

## 5.8 XOnNTX\_SMRBufInfo

Returns informations on a ring-buffer.

### Connector Pane



### Controls and Indicators

#### **SMRBuf**

Handle of a ring-buffer.

XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **SMRBuf/dup**

Duplicated ring-buffer handle.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **SMRBufInfo**

Ring-buffer info structure.

##### **Align**

Current buffer alignment in bytes.

##### **WrtCount**

Nr. of bytes ever written to the ring-buffer.

##### **BufSize**

Max. nr. of bytes the buffer can hold.

##### **Overrun**

Nr. of overrun-bytes.

##### **ReadAvail**

Nr. of bytes currently available for read-operations.

##### **WriteAvail**

Nr. of bytes currently free for write-operations.

##### **SMemHdl**

Handle of the shared-memory object the ring-buffer is based on.

#### WARNING:

You should NOT write directly to the shared memory. This destroys administration structures and will lead to errors and/or system-crashes.

##### **hMutex**

Handle of the mutex-object internally used to synchronize buffer-access.

##### **hReadEvt**

Handle of the read-event-object that will be signaled on read-operations (may be 0 if not created).

WARNING: Use this handle only for wait-operations.

##### **hWriteEvt**

Handle of the write-event-object that will be signaled on write-operations (may be 0 if not created).

WARNING: Use this handle only for wait-operations.

##### **Mutex**

Name of mutex object.



**abc** **ReadEvt**

Name of read-event-object. May be empty if not created.


**abc** **WriteEvt**

Name of write-event-object. May be empty if not created.

## 5.9 XOnNTX\_SMRBufOpen

Opens an existing ring-buffer (named or unnamed).  
Returns an error if ring-buffer could not be opened (does not exist).

### Connector Pane



### Controls and Indicators

#### Name

Name of existing ring-buffer (optional).  
Unnamed ring-buffers must be created by the same process to be opened by this functions.  
Named ring-buffers can be created by other processes in the system.

#### EvtMode(No)

Eventmode.  
On Eventmodes other than 'NoEvt' the ring-buffer administration creates a named Read- and/or Write-Eventobject that may be used to synchronize read- and write-operations.  
A read-event will be signaled if any ring-buffer user reads data or clears the ring-buffer.  
A write-event will be signaled on write-operations.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### IOHandle

Driver-handle.

### **MtxWaitMS(10)**

Mutexwait Timeout (optional).

The buffer administration always creates a named mutex-object for a ring-buffer. It is used to synchronize the access to internal structures for parallel processes. While one process is reading or writing to the buffer other processes wait on this mutex-object.

The 'MtxWaitMS' parameter sets the timeout value in milliseconds for this wait-operation. If a wait timed out on a read or write, the function will return an error.

### **SMRBuf**

Handle of the opened shared memory based ring-buffer.

Use this handle with other XOnNTX\_SMRB.. functions.

### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


### **IOHandle/dup**

Duplicated Driver-handle.

## 5.10 XOnNTX\_SMRBufRead

Reads up to 'MaxSize' bytes from the ring-buffer.  
The function does not wait until enough data are in the buffer. If less than 'MaxSize' bytes are available only the entire buffer contents will be returned.

### Connector Pane



### Controls and Indicators

#### **SMRBuf**

Handle of a ring-buffer.  
XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **MaxSize**

Max. nr. of bytes to be read from the ring-buffer.

#### **SMRBuf/dup**

Duplicated ring-buffer handle.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error,

if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

** Data/raw**

Read data in raw-format.


** Overrun**

Nr. of overrun-bytes since last read operation.

## 5.11 XOnNTX\_SMRBufReadEx

Reads up to 'MaxSize' bytes from the ring-buffer.  
The function waits upto 'WaitMS' milliseconds until enough data is in the buffer. If the wait timed out only the entire buffer-contents will be returned.  
While waiting, the function allows write-operations from other processes (threads). This allows to read more data as the ring-buffer can hold.

### Connector Pane



### Controls and Indicators



#### SMRBuf

Handle of a ring-buffer.  
XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.



#### WaitMS(0)

Max. nr. of milliseconds to wait until enough data are in the buffer.



#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



#### MaxSize

Max. nr. of bytes to be read from the ring-buffer.



#### SMRBuf/dup

Duplicated ring-buffer handle.

** error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

** Data/raw**

Read data in raw-format.

** Overrun**

Nr. of overrun-bytes since last read operation.

## 5.12 XOnNTX\_SMRBufWrite

Writes (appends) data into the ring-buffer.

The function will overwrite existing data if not enough free space is available. The function does not write more than the max. size the buffer can hold.

### Connector Pane



### Controls and Indicators



#### SMRBuf

Handle of a ring-buffer.

XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.



#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



#### Data/raw

Data in raw format to write.



#### SMRBuf/dup

Duplicated ring-buffer handle.



#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display

the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**TF** **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**I32** **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**abc** **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


**U32** **Written**

Nr. of bytes written.

## 5.13 XOnNTX\_SMRBufWriteEx

Writes (appends) data into the ring-buffer.  
The function waits up to 'WaitMS' milliseconds until enough space is available to write the data. While waiting, the function allows read-operations from other processes (threads). This allows to write more data than the ring-buffer can hold.

### Connector Pane



### Controls and Indicators



#### SMRBuf

Handle of a ring-buffer.

XOnNTX\_SMRBufCreate or XOnNTX\_SMRBufOpen returns this handle.



#### WaitMS(0)

Max. nr. of milliseconds to wait until enough free space is available.



#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.



#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.



#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.



#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.



#### Data/raw

Data in raw format to write.



#### SMRBuf/dup

Duplicated ring-buffer handle.

**error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

**status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

**code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

**source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.


**Written**

Nr. of bytes written.

## 6 XOnNTX\_Utility\_VIs

### 6.1 XOnNTX\_MoveMemory

#### Connector Pane



#### Controls and Indicators

 **DstAddr**

 **SrcAddr**

 **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **Length**

 **DstAddr/dup**

 **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display

the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** source**


source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

** SrcAddr/dup**

## 6.2 XOnNTX\_ReadByte

Read a byte (u8) from given virtual address.

### Connector Pane



### Controls and Indicators

#### VirtAddr

Virtual start address.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### VirtAddr/dup

Duplicated virtual address.

#### Byte

Read value.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.3 XOnNTX\_ReadDWord

Read a doubleword (u32) from given virtual address.

### Connector Pane



### Controls and Indicators

#### **VirtAddr**

Virtual start address.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **VirtAddr/dup**

Duplicated virtual address.

#### **DWord**

Read value.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.4 XOnNTX\_ReadMemory

Read 'Length' bytes starting at given virtual address.

### Connector Pane



### Controls and Indicators

#### VirtAddr

Virtual start address.

#### Length

Nr. of bytes to read.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### VirtAddr/dup

Duplicated start address.

#### Data

Read data.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display

the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


** source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.5 XOnNTX\_ReadString

Read a string of max. length 'MaxLen' starting at given virtual address.

### Connector Pane



### Controls and Indicators

 **VirtAddr**  
Virtual start address.

 **MaxLen(1024)**  
Max. stringlength.

 **error in (no error)**  
error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

 **status**  
status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

 **code**  
code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

 **source**  
source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

 **VirtAddr/dup**  
Duplicated virtual address.

 **Data**  
Read string.

 **error out**  
error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display

the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.6 XOnNTX\_ReadWord

Read a word (u16) from given virtual address.

### Connector Pane



### Controls and Indicators

#### **VirtAddr**

Virtual start address.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **VirtAddr/dup**

Duplicated virtual address.

#### **Word**

Read value.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.


** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.7 XOnNTX\_WriteByte

Write a byte (u8) to the given virtual address.

### Connector Pane



### Controls and Indicators

#### VirtAddr

Virtual start address.

#### Byte(0)

Value to write.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### VirtAddr/dup

Duplicated virtual address.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.8 XOnNTX\_WriteDWord

Write a doubleword (u32) to the given virtual address.

### Connector Pane



### Controls and Indicators

#### **VirtAddr**

Virtual start address.

#### **DWord(0)**

Value to write.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **VirtAddr/dup**

Duplicated virtual address.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

### **status**

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.9 XOnNTX\_WriteMemory

Writes data to the given virtual address.

### Connector Pane



### Controls and Indicators

#### VirtAddr

Virtual start address.

#### Data

Data to write.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### VirtAddr/dup

Duplicated start address.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.10 XOnNTX\_WriteString

Write string 'Data' to the given virtual address.

### Connector Pane



### Controls and Indicators

#### VirtAddr

Virtual start address.

#### Data

String to write.

#### error in (no error)

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### status

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### code

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### source

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### VirtAddr/dup

Duplicated start address.

#### error out

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 6.11 XOnNTX\_WriteWord

Write a word (u16) to the given virtual address.

### Connector Pane



### Controls and Indicators

#### **VirtAddr**

Virtual start address.

#### **Word(0)**

Value to write.

#### **error in (no error)**

error in is a cluster that describes the error status before this VI executes. If error in indicates that an error occurred before this VI was called, this VI may choose not to execute its function, but just pass the error through to its error out cluster. If no error has occurred, then this VI executes normally and sets its own error status in error out. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

#### **status**

status is TRUE if an error occurred before this VI was called, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

#### **code**

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

#### **source**

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

#### **VirtAddr/dup**

Duplicated virtual address.

#### **error out**

error out is a cluster that describes the error status after this VI executes. If an error occurred before this VI was called, error out is the same as error in. Otherwise, error out shows the error, if any, that occurred in this VI. Use the error handler VIs to look up the error code and to display the corresponding error message. Using error in and error out clusters is a convenient way to check errors and to specify execution order by wiring the error output from one subVI to the error input of the next.

** **status****

status is TRUE if an error occurred, or FALSE if not. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code.

** **code****

code is the number identifying an error or warning. If status is TRUE, code is a non-zero error code. If status is FALSE, code can be zero or a warning code. Use the error handler VIs to look up the meaning of this code and to display the corresponding error message.

** **source****

source is a string that indicates the origin of the error, if any. Usually source is the name of the VI in which the error occurred.

## 7 Constants and Types

### 7.1 XOnNTX\_HardIO

#### 7.1.1 PCI\_COMMON\_CONFIG

---

#### Connector Pane





## 7.1.2 PCI\_CONFIG

---

### Connector Pane



## 7.2 XOnNTX\_BaseIO

### 7.2.1 IOHANDLE

---

#### Connector Pane





## 7.2.2 XONNTX\_DIAGINFO

---

### Connector Pane



## 7.3 XOnNTX\_ShareM

### 7.3.1 SMEMHDL

Handle of shared memory.

---

#### Connector Pane





## 7.3.2 SMEMINFO

Infostructure for information on shared memory objects.

---

### Connector Pane



### 7.3.3 SMRBUFHDL

Handle of a shared memory based ring-buffer.

---

#### Connector Pane





## 7.3.4 SMRBUFINFO

Ring-Buffer info.

---

### Connector Pane



## 8 Contact



### **XOn Software GmbH**

Luisenstraße 43

80333 München

Telefon: +49 (0)89/542716-0

Telefax: +49 (0)89/542716-78

E-mail: [info@xon.de](mailto:info@xon.de)

Internet: <http://www.xon.de>

### **Your partner for ...**

LabVIEW, LabWindows/CVI, Microsoft Visual C++, National Instruments Hardware, GPIB, CAN, Profibus, RS232, RS 485...

# Index

## - C -

Close 11  
CloseSharedMemory 65  
Contact 122  
CreateSharedMemory 67

## - D -

DisablePortIO 23

## - E -

EnablePortIO 25

## - G -

GetDiagnosis 13  
GetPhysAddress 27  
GetPortIOMap 29

## - I -

InfoSharedMemory 69  
InpB 31  
InpD 32  
InpW 33  
IOClose 6  
IOHANDLE 116  
IOOpen 7  
IORead 8  
IOWrite 9

## - M -

MapPhysMemory 34  
MoveMemory 92

## - N -

NTX\_Close 11  
NTX\_CloseSharedMemory 65

NTX\_CreateSharedMemory 67  
NTX\_DisablePortIO 23  
NTX\_EnablePortIO 25  
NTX\_GetDiagnosis 13  
NTX\_GetPhysAddress 27  
NTX\_GetPortIOMap 29  
NTX\_InfoSharedMemory 69  
NTX\_InpB 31  
NTX\_InpD 32  
NTX\_InpW 33  
NTX\_MapPhysMemory 34  
NTX\_MoveMemory 92  
NTX\_Open 16  
NTX\_OpenSharedMemory 71  
NTX\_OutB 36  
NTX\_OutD 37  
NTX\_OutW 38  
NTX\_PCICountDevice 39  
NTX\_PCIFindDevice 41  
NTX\_PCIGetConfig 43  
NTX\_PCISetConfig 52  
NTX\_ReadByte 94  
NTX\_ReadDWord 96  
NTX\_ReadMemory 98  
NTX\_ReadPort 18  
NTX\_ReadString 100  
NTX\_ReadWord 102  
NTX\_SetPortIOMap 61  
NTX\_SMRBufClear 73  
NTX\_SMRBufClose 75  
NTX\_SMRBufCreate 77  
NTX\_SMRBufInfo 79  
NTX\_SMRBufOpen 82  
NTX\_SMRBufRead 84  
NTX\_SMRBufReadEx 86  
NTX\_SMRBufWrite 88  
NTX\_SMRBufWriteEx 90  
NTX\_UnmapPhysMemory 63  
NTX\_Version 20  
NTX\_WriteByte 104  
NTX\_WriteDWord 106  
NTX\_WriteMemory 108  
NTX\_WritePort 21  
NTX\_WriteString 110  
NTX\_WriteWord 112

**- O -**

Open 16  
 OpenSharedMemory 71  
 OutB 36  
 OutD 37  
 OutW 38

**- P -**

PCI\_COMMON\_CONFIG 114  
 PCI\_CONFIG 115  
 PCICountDevice 39  
 PCIFindDevice 41  
 PCIGetConfig 43  
 PCISetConfig 52

**- R -**

ReadByte 94  
 ReadDWord 96  
 ReadMemory 98  
 ReadPort 18  
 ReadString 100  
 ReadWord 102

**- S -**

SetPortIOMap 61  
 SMEMHDL 118  
 SMEMINFO 119  
 SMRBufClear 73  
 SMRBufClose 75  
 SMRBufCreate 77  
 SMRBUFHDL 120  
 SMRBufInfo 79, 121  
 SMRBufOpen 82  
 SMRBufRead 84  
 SMRBufReadEx 86  
 SMRBufWrite 88  
 SMRBufWriteEx 90

**- U -**

UnmapPhysMemory 63

**- V -**

Version 20

**- W -**

WriteByte 104  
 WriteDWord 106  
 WriteMemory 108  
 WritePort 21  
 WriteString 110  
 WriteWord 112

**- X -**

XOn 122  
 XOn Contact 122  
 XOnNTX\_Close 11  
 XOnNTX\_CloseSharedMemory 65  
 XOnNTX\_CreateSharedMemory 67  
 XONNTX\_DIAGINFO 117  
 XOnNTX\_DisablePortIO 23  
 XOnNTX\_EnablePortIO 25  
 XOnNTX\_GetDiagnosis 13  
 XOnNTX\_GetPhysAddress 27  
 XOnNTX\_GetPortIOMap 29  
 XOnNTX\_InfoSharedMemory 69  
 XOnNTX\_InpB 31  
 XOnNTX\_InpD 32  
 XOnNTX\_InpW 33  
 XOnNTX\_MapPhysMemory 34  
 XOnNTX\_MoveMemory 92  
 XOnNTX\_Open 16  
 XOnNTX\_OpenSharedMemory 71  
 XOnNTX\_OutB 36  
 XOnNTX\_OutD 37  
 XOnNTX\_OutW 38  
 XOnNTX\_PCICountDevice 39  
 XOnNTX\_PCIFindDevice 41  
 XOnNTX\_PCIGetConfig 43  
 XOnNTX\_PCISetConfig 52  
 XOnNTX\_ReadByte 94  
 XOnNTX\_ReadDWord 96  
 XOnNTX\_ReadMemory 98  
 XOnNTX\_ReadPort 18  
 XOnNTX\_ReadString 100



XOnNTX_ReadWord	102
XOnNTX_SetPortIOMap	61
XOnNTX_SMRBufClear	73
XOnNTX_SMRBufClose	75
XOnNTX_SMRBufCreate	77
XOnNTX_SMRBufInfo	79
XOnNTX_SMRBufOpen	82
XOnNTX_SMRBufRead	84
XOnNTX_SMRBufReadEx	86
XOnNTX_SMRBufWrite	88
XOnNTX_SMRBufWriteEx	90
XOnNTX_UnmapPhysMemory	63
XOnNTX_Version	20
XOnNTX_WriteByte	104
XOnNTX_WriteDWord	106
XOnNTX_WriteMemory	108
XOnNTX_WritePort	21
XOnNTX_WriteString	110
XOnNTX_WriteWord	112